



# Coaxlink Duo PCIe/104-EMB

Two-connection ruggedized CoaXPress frame grabber



## At a Glance

- Ruggedized board for industrial and transportation embedded applications
- Small stackable PCIe/104 form factor
- Extended temperature range: -40 to +85°C / -40 to +185°F
- Sustained shock: 40 g/11ms (all axes - half-sine and saw tooth)
- Optional conformal coating
- Two CoaXPress CXP-6 connections: 1,250 MB/s camera bandwidth
- PCIe 2.0 (Gen 2) x4 bus: 1,700 MB/s delivery bandwidth

## Benefits

### Ruggedized CoaXPress Frame Grabber

- Compliant with the PCIe/104 form factor.
- Extended operating temperature range.
- Withstand high levels of shock and vibration.
- Two CoaXPress CXP-6 (6 Gbit/s) camera connections.
- PCIe 2.0 (Gen 2) x4 bus.

### PCIe/104 ruggedized board design

- Compact size: 90 x 96 mm module size - reduced footprint for smaller electronic devices
- Self-stacking: expands without backplanes or card cages
- Rugged, reliable connectors: reliable in harsh environments
- Four-corner mounting holes: resistance to shock and vibration
- Fully PC compatible: reduced development costs and time-to-market
- Backward compatibility with current PC/104 specifications and form factors
- Interoperability across manufacturers

### Use heavy duty coaxial cables

- A single inexpensive cable for data transfer, camera control, trigger and power supply

- Top reliability and flexibility, performs in the harshest environments

### **Use robust remote connectors**

- Remote DIN 1.0/2.3 connectors (other connector types available on request)
- Remote I/O connectors on separate board
- Connectors can be customized and installed on enclosure at convenient locations

### **Modular architecture**

The following optional accessories are available:

- 3300 HD26F I/O module for Coaxlink Duo PCIe/104: A remote module that can be installed at a convenient location on the enclosure.
- 3301 Thermal drain (Model 1) for Coaxlink Duo PCIe/104
- 3302 DIN1.0/2.3 Coaxial cable for Coaxlink Duo PCIe/104

### **Long cable support**

- 40 meters at CXP-6 speed (6.25 Gbps)
- 100 meters at CXP-3 speed (3 Gbps)

### **Acquire images from the fastest and highest resolution cameras**

- Highest data acquisition rate in the industry
- 12.5 Gbit/s (1,250 MB/s) bandwidth from camera to host PC memory

### **Memento Event Logging Tool**

- Memento is an advanced development and debugging tool available for Coaxlink cards.
- Memento records an accurate log of all the events related to the camera, the frame grabber and its driver as well as the application.
- It provides the developer with a precise timeline of time-stamped events, along with context information and logic analyzer view.
- It provides valuable assistance during application development and debugging, as well as during machine operation.

### **Direct GPU transfer**

- Sample programs for AMD DirectGMA and NVIDIA (CUDA) available.
- Direct GPU transfer eliminates unnecessary system memory copies, lowers CPU overhead, and reduces latency, resulting in significant performance improvements in data transfer times for applications.
- Direct capture of image data to GPU memory is available using AMD's DirectGMA. Compatible with AMD FirePro W5x00 and above and all AMD FirePro S series products.

### **PCIe 2.0 (Gen 2) x4 universal expansion bus (Type 1 or Type 2)**

- 1,700 MB/s sustained bus bandwidth

### **General purpose I/O lines**

- Compatible with a wide range of sensors and motion encoders.
- High-speed differential inputs: Quadrature motion encoder support up to 5 MHz.
- Isolated current-sense inputs: 5V, 12V, 24V signaling voltages accepted, up to 50 kHz, individual galvanic isolation up to 500VAC RMS.
- Isolated contact outputs.
- High-speed 5V-compliant TTL inputs/ LVTTTL outputs.

### **High-performance DMA (Direct Memory Access)**

- Direct transfer into user-allocated memory and hardware boards that expose PCI addresses
- Hardware scatter-gather support
- 64-bit addressing capability

### **Area-scan triggering capabilities**

- A trigger is used to start the acquisition when the part is in position. Hardware triggers come from the Coaxlink's I/O lines. Software triggers come from the application.
- An optional trigger delay is available to postpone the acquisition for a programmable time.
- A trigger decimation function allows to skip some of the triggers.
- Camera exposure control allows the application to control the exposure time of the camera.
- When the acquisition starts, at the appropriate timing, the Coaxlink board generates a signal to control an illumination device connected to one of its output lines.

### Line-scan triggering capabilities

Coaxlink supports continuous web scanning (to inspect infinite, continuously moving surfaces without losing a single line) and discrete object scanning (to acquire the image of objects moving in front of the camera).

- A trigger is used to start the acquisition when the part is in position. Hardware triggers come from the board's I/O lines. Software triggers come from the application.
- After it is started, the acquisition either:
  - Continues indefinitely (for web inspection applications)
  - Continues for a programmable number of lines (to acquire the image of objects of a known length)
  - Continues until an end trigger is received (to acquire the image of objects of a variable length)
- An optional trigger delay is available to postpone the beginning of the acquisition for a programmable number of lines.

### Line-scan triggering capabilities

- The Coaxlink frame grabber controls the camera scanning rate based on the signals received from a motion encoder. When the parts move faster, the acquisition line rate of the camera increases. When the parts move slower, the acquisition line rate of the camera decreases.
- The Coaxlink boards interpret A/B signals from quadrature motion encoders to know in which direction (forward or backward) the part is moving.
- Optionally, the Coaxlink can be instructed to acquire lines only when the object is moving forward or only when the object is moving backward.
- A feature called Backward Motion Cancellation stops the acquisition when a backward motion is detected. The line acquisition automatically resumes when the motion is again in the forward direction, at the exact place where the acquisition was interrupted.
- A Rate Converter allows the camera to acquire lines at any programmable resolution lower or higher than the resolution of the motion encoder. This gives the designer incredible freedom and flexibility during the development of the application.
- A Rate Divider allows the camera to acquire lines at a resolution lower than the resolution of the motion encoder. It divides the frequency of the incoming encoder signal by a programmable integer.

### Flexible line-scan camera operation with the rate converter.

- The rate converter is a smart, programmable frequency multiplier/divider.
- Used with motion encoders and line-scan cameras, it allows the user to choose the aspect ratio of the pixels in the image.
- It provides a way to calibrate the acquisition chain to easily reach square (1:1 aspect ratio) pixels.

### The Coaxlink driver includes the following tools:

- Genicam Browser: An application giving access to the Genicam features exposed by the GenTL Producer(s) in the system.
- GenTL Console: A command-line tool giving access to the functions and commands exposed by the Euresys GenTL Producer.

### Compliant with Genicam Including support for

- GenApi
- The Standard Feature Naming Convention (SFNC)
- GenTL

### Windows, Linux and macOS drivers available

- Including support for Intel 32-bit and 64-bit platforms as well as ARM 64-bit platforms

## Applications

### Video Acquisition and Recording

- High-frame-rate video acquisition for motion analysis and recording
- Scientific research, hyperspectral imaging

### Video Monitoring, Surveillance & Security

- Transmission and acquisition of high-definition video over long coaxial cables for traffic surveillance, monitoring and control
- Embedded security systems for rail and road transportation, police vehicles

## Specifications

### Mechanical

|                 |  |
|-----------------|--|
| Form Factor     | PCIe/104 card  |
| Format          | 4-lane PCIe/104, stack-down only, universal peripheral module  |
| Cooling method  | Conduction cooling   |
| Mounting        | For stacking down directly under the Host PC: <ul style="list-style-type: none"><li>• 1 or 2 modules on Type 1 and Type 2 Host PC's</li></ul>  |
| Connectors      | <ul style="list-style-type: none"><li>• 'CAMERA POWER INPUT'<ul style="list-style-type: none"><li>– 4-pin 0.1-in Molex KK 7478 male connector</li></ul></li><li>• 'C2C-Link'<ul style="list-style-type: none"><li>– 6-pin 2-row 0.1-in header</li></ul></li><li>• 'I/O' on '3300 HD26F I/O module for Coaxlink Duo PCIe/104' (optional)<ul style="list-style-type: none"><li>– 26-pin 3-row high-density female sub-D connector</li><li>– GPIO lines and power output</li></ul></li><li>• 'A', 'B' on '3302 DIN1.0/2.3 Coaxial cable for Coaxlink Duo PCIe/104' (optional)<ul style="list-style-type: none"><li>– DIN 1.0/2.3 female connectors</li><li>– CoaXPress host interface</li></ul></li></ul> |
| Lamp indicators | <ul style="list-style-type: none"><li>• 'A', 'B' on '3300 HD26F I/O module for Coaxlink Duo PCIe/104' (optional)<ul style="list-style-type: none"><li>– 2x bi-color red/green LEDs</li><li>– CoaXPress Host connector indicator lamps</li></ul></li><li>• 'FPGA STATUS LAMP' on '3300 HD26F I/O module for Coaxlink Duo PCIe/104' (optional)<ul style="list-style-type: none"><li>– Bi-color red/green LED</li></ul></li><li>• 'BOARD STATUS LAMP' on '3300 HD26F I/O module for Coaxlink Duo PCIe/104' (optional)<ul style="list-style-type: none"><li>– Bi-color red/green LED</li></ul></li></ul>   |
| Switches        | 'RECOVERY' on card PCB: <ul style="list-style-type: none"><li>• 3-pin 1-row 0.1" header</li><li>• Firmware emergency recovery</li></ul>  |
| Dimensions      | 96 mm x 90 mm<br>3.775 in x 3.555 in   |
| Weight          | 75 g, 2.65 oz without accessories  |

### Host bus

|            |  |
|------------|--|
| Standard   | PCI Express 2.0  |
| Link width | <ul style="list-style-type: none"><li>• 4 lanes</li><li>• 1 lane or 2 lanes with reduced performance</li></ul> |

|  |   |
|--|---|
| Link speed                               | <ul style="list-style-type: none"> <li>• 5.0 GT/s (PCIe 2.0)</li> <li>• 2.5 GT/s (PCIe 1.0) with reduced performance</li> </ul>     |
| Maximum payload size                     | 512 bytes   |
| DMA                                      | 32- and 64-bit  |
| Peak delivery bandwidth                  | 2,000 MB/s  |
| Effective (sustained) delivery bandwidth | 1,700 MB/s (Host PC motherboard dependent)  |
| Power consumption                        | Typ. 8.4 W @ +12V excluding I/O power output <ul style="list-style-type: none"> <li>• +3.3V and +5.0V rails are not used</li> </ul> |

## Camera / video inputs

|  |   |
|--|---|
| Interface standard(s)                        | CoaXPress 1.0, 1.1 and 1.1.1  |
| Connectors                                   | 2x MCX 75 Ohms CXP-6  |
| Status LEDs                                  | 1 CoaXPress Host connection status per connector  |
| Number of cameras                            | <ul style="list-style-type: none"> <li>• Area-scan cameras:             <ul style="list-style-type: none"> <li>– One 1- or 2-connection camera</li> <li>– One or two 1-connection cameras</li> </ul> </li> <li>• Line-scan cameras:             <ul style="list-style-type: none"> <li>– One 1- or 2-connection camera</li> </ul> </li> </ul>   |
| Line-scan cameras supported                  | Yes   |
| Maximum aggregated camera data transfer rate | 12.5 Gbit/s (1,250 MB/s)  |
| Supported CXP down-connection speeds         | 1.25 GT/s (CXP-1), 2.5 GT/s (CXP-2), 3.125 GT/s (CXP-3), 5 GT/s (CXP-5), and 6.25 GT/s (CXP-6)  |
| Number of CXP data streams (per camera)      | 1 data stream per camera  |
| Maximum CXP stream packet size               | 16,384 bytes  |
| PoCXP (Power over CoaXPress)                 | <ul style="list-style-type: none"> <li>• PoCXP Safe Power:             <ul style="list-style-type: none"> <li>– 17 W of 24V DC power per CoaXPress connector</li> <li>– PoCXP Device detection and automatic power-on</li> <li>– Overload and short-circuit protections</li> </ul> </li> <li>• A +24V DC power source must be connected to the CAMERA POWER INPUT connector on the module</li> </ul>  |
| Camera types                                 | <ul style="list-style-type: none"> <li>• Area-scan cameras:             <ul style="list-style-type: none"> <li>– Gray-scale and color (YCbCr, YUV, RGB and Bayer CFA)</li> <li>– Single-tap (1X-1Y) progressive-scan</li> </ul> </li> <li>• Line-scan cameras and contact imaging sensors:             <ul style="list-style-type: none"> <li>– Gray-scale and color RGB</li> </ul> </li> </ul>   |
| Camera pixel formats supported               | Raw, Monochrome, Bayer, RGB, and RGBA (PFNC names): <ul style="list-style-type: none"> <li>• Raw</li> <li>• Mono8, Mono10, Mono12, Mono14, Mono16</li> <li>• BayerXX8, BayerXX10, BayerXX12, BayerXX14, BayerXX16 where XX = GR, RG, GB, or BG</li> <li>• RGB8, RGB10, RGB12, RGB14, RGB16</li> <li>• RGBA8, RGBA10, RGBA12, RGBA14, RGBA16</li> <li>• YCbCr601_422_8, YCbCr601_422_10</li> <li>• YCbCr709_422_8, YCbCr709_422_10</li> <li>• YUV422_8, YUV422_10</li> </ul> |

## Area-scan camera control

---

|         |   |
|---------|---|
| Trigger | <ul style="list-style-type: none"><li>• Precise control of asynchronous reset cameras, with exposure control.</li><li>• Support of camera exposure/readout overlap.</li><li>• Support of external hardware trigger, with optional delay and trigger decimation.</li></ul> |
| Strobe  | <ul style="list-style-type: none"><li>• Accurate control of the strobe position for strobed light sources.</li><li>• Support of early and late strobe pulses.</li></ul>   |

---

## Line-scan camera control

---

|                   |   |
|-------------------|---|
| Scan/page trigger | <ul style="list-style-type: none"><li>• Precise control of start-of-scan and end-of-scan triggers.</li><li>• Support of external hardware trigger, with optional delay.</li><li>• Support of infinite acquisition, without missing line, for web inspection applications.</li></ul>   |
| Line trigger      | <ul style="list-style-type: none"><li>• Support for quadrature motion encoders, with programmable noise filters, selection of acquisition direction and backward motion compensation.</li><li>• Rate Converter tool for fine control of the pixel aspect ratio: Rate Conversion Ratio in the range 0.001 to 1000 with an accuracy better than 0.1%.</li><li>• Rate Divider tool</li></ul> |
| Line strobe       | <ul style="list-style-type: none"><li>• Accurate control of the strobe position for strobed light sources.</li></ul>  |

---

## On-board processing

---

|                              |  |
|------------------------------|--|
| On-board memory              | 512 MB   |
| Image data stream processing | <ul style="list-style-type: none"><li>• Unpacking of 10-/12-/14-bit to 16-bit with selectable justification to LSB or MSB</li><li>• Optional swap of R and B components</li><li>• Little endian conversion</li></ul>   |
| Data stream statistics       | <ul style="list-style-type: none"><li>• Measurement of:<ul style="list-style-type: none"><li>– Frame rate (Area-scan only)</li><li>– Line rate</li><li>– Data rate</li></ul></li><li>• Configurable averaging interval</li></ul>   |
| Event signaling and counting | <ul style="list-style-type: none"><li>• The application software can be notified of the occurrence of various events:<ul style="list-style-type: none"><li>– Standard event: the EVENT_NEW_BUFFER event notifies the application of newly filled buffers</li><li>– A large set of custom events</li></ul></li><li>• Custom events sources:<ul style="list-style-type: none"><li>– I/O Toolbox events</li><li>– Camera and Illumination control events</li><li>– CoaXPress data stream events</li><li>– CoaXPress host interface events</li></ul></li><li>• Each custom event is associated with a 32-bit counter that counts the number of occurrences</li><li>• The last three 32-bit context data words of the event context data can be configured with event-specific context data:<ul style="list-style-type: none"><li>– Event-specific data</li><li>– State of all System I/O lines sampled at the event occurrence time</li><li>– Value of any event counter</li></ul></li></ul> |
| Input LUT (Lookup Table)     | <ul style="list-style-type: none"><li>• Available for monochrome cameras<ul style="list-style-type: none"><li>– 8 to 8 bits</li><li>– 10 to 8, 10 or 16 bits</li><li>– 12 to 8, 12 or 16 bits</li></ul></li></ul>  |

---

## General Purpose Inputs and Outputs

|                           |  |
|---------------------------|--|
| Number of lines           | <p>310 I/O lines on '3300 HD26F I/O module for Coaxlink Duo PCIe/104':</p> <ul style="list-style-type: none"> <li>• 2 differential inputs (DIN)</li> <li>• 2 singled-ended TTL inputs/outputs (TTLIO)</li> <li>• 4 isolated inputs (IIN)</li> <li>• 2 isolated outputs (IOUT)</li> </ul>   |
| Usage                     | <ul style="list-style-type: none"> <li>• Any I/O input lines can be used by any LIN tool of the I/O Toolbox</li> <li>• Selected pairs of I/O input lines can be used by any QDC tool of the I/O toolbox to decode A/B signals of a motion encoder</li> <li>• The LIN and QDC tools outputs can be further processed by the other tools (DIV, MDV, DEL) of the I/O toolbox to generate any of the following "trigger" events: <ul style="list-style-type: none"> <li>– The "cycle trigger" of the Camera and Illumination controller</li> <li>– The "cycle sequence trigger" of the Camera and Illumination controller</li> <li>– The "start-of-scan trigger" of the Acquisition Controller (line-scan only)</li> <li>– The "end-of-scan trigger" of the Acquisition Controller (line-scan only)</li> </ul> </li> </ul>   |
| Electrical specifications | <ul style="list-style-type: none"> <li>• DIN: High-speed differential inputs compatible with ANSI/EIA/TIA-422/485 differential line drivers and complementary TTL drivers</li> <li>• TTLIO: High-speed 5V-compliant TTL inputs or LVTTTL outputs, compatible with totem-pole LVTTTL, TTL, 5V CMOS drivers or LVTTTL, TTL, 3V CMOS receivers</li> <li>• IIN: Isolated current-sense inputs with wide voltage input range up to 30V, compatible with totem-pole LVTTTL, TTL, 5V CMOS drivers, RS-422 differential line drivers, potential free contacts, solid-state relays and opto-couplers</li> <li>• IOUT: Isolated contact outputs compatible with 30V / 100mA loads</li> </ul>   |
| Filter control            | <ul style="list-style-type: none"> <li>• Glitch removal filter available on all System I/O input lines</li> <li>• Configurable filter time constants: <ul style="list-style-type: none"> <li>– for DIN and TTLIO lines: 50 ns, 100 ns, 200 ns, 500 ns, 1 <math>\mu</math>s</li> <li>– for IIN lines: 500 ns, 1 <math>\mu</math>s, 2 <math>\mu</math>s, 5 <math>\mu</math>s, 10 <math>\mu</math>s</li> </ul> </li> </ul>  |
| Polarity control          | Yes  |
| Power output              | <p>On '3300 HD26F I/O Module for Coaxlink Duo PCIe/104':</p> <p>Non-isolated, +12V, 1A, with electronic fuse protection</p>  |
| I/O Toolbox tools         | <p>The I/O Toolbox is a configurable interconnection of tools that generates events (usually triggers) from input lines. The composition of the toolset is product- and firmware-dependent.</p> <ul style="list-style-type: none"> <li>• Line Input tool (LIN): Edge detector delivering events on rising or falling edges of any selected input line.</li> <li>• Quadrature Decoder tool (QDC): A composite tool including: <ul style="list-style-type: none"> <li>– A quadrature edge detector delivering events on selected transitions of selected pairs of input lines.</li> <li>– An optional backward motion compensator for clean line-scan image acquisition when the motion is unstable.</li> <li>– A 32-bit up/down counter for delivering a position value.</li> </ul> </li> <li>• Divider tool (DIV): to generate an event every nth input events from any I/O toolbox event source.</li> <li>• Multiplier/divider tool (MDV): to generate m events every d input events from any I/O toolbox event source.</li> <li>• Delay tool (DEL): to delay up to 16 events from one or two I/O toolbox event sources, by a programmable time or number of motion encoder ticks (any QDC events).</li> <li>• User Actions Scheduler tool (UAS): to delegate the execution of User Actions at a scheduled time or encoder position. Possible user actions include setting low/high/toggle any bit of the User Output Register or generation of any User Events.</li> </ul> |

|                         |   |
|-------------------------|---|
| I/O Toolbox composition | Firmware-dependent I/O toolbox composition: <ul style="list-style-type: none"> <li>• 1-camera: 8 LIN, 1 QDC, 1 DIV, 1 MDV, 2 DEL, 1 UAS</li> <li>• 2-camera: 8 LIN, 1 QDC, 1 DIV, 1 UAS</li> <li>• 1-camera, line-scan: 8 LIN, 1 QDC, 1 DIV, 1 MDV, 2 DEL, 1 UAS</li> </ul> |
|-------------------------|---|

## C2C-Link

|               |  |
|---------------|--|
| Description   | <ul style="list-style-type: none"> <li>• Allows to accurately synchronize the trigger and start-of-exposure of multiple grabber-controlled area-scan and line-scan cameras.</li> <li>• C2C-Link is able to synchronize cameras connected             <ul style="list-style-type: none"> <li>– to the same Coaxlink card</li> <li>– to different cards in the same PC (requires an accessory cable such as the "3303 C2C-Link Ribbon Cable" or a custom-made C2C-Link cable)</li> </ul> </li> </ul> |
| Specification | <ul style="list-style-type: none"> <li>• Maximum distance: 60 cm</li> <li>• Maximum trigger rate: 2.5 MHz</li> <li>• Trigger propagation delay from master to slave devices: Less than 10 ns</li> </ul>  |

## Software

|                          |  |
|--------------------------|--|
| Host PC Operating System | <ul style="list-style-type: none"> <li>• Microsoft Windows 10, 8.1, 7 for x86 (32-bit) and x86-64 (64-bit) processor architectures</li> <li>• Linux for x86 (32-bit), x86-64 (64-bit) and aarch64 (64-bit) processor architectures</li> <li>• macOS for x86-64 (64-bit) processor architecture</li> </ul> <p>Refer to release notes for details</p>  |
| APIs                     | <p>EGrabber class, with C++ and .NET APIs:</p> <ul style="list-style-type: none"> <li>• .NET assembly designed to be used with development environments compatible with .NET frameworks version 2.0 or higher</li> </ul> <p>GenICam GenTL producer libraries compatible with C/C++ compilers:</p> <ul style="list-style-type: none"> <li>• x86 dynamic library designed to be used with ISO-compliant C/C++ compilers for the development of x86 applications</li> <li>• x86_64 dynamic library designed to be used with ISO-compliant C/C++ compilers for the development of x86_64 applications</li> <li>• aarch64 dynamic library designed to be used with ISO-compliant C/C++ compilers for the development of aarch64 applications</li> </ul> |
| Memento                  | Compatible with Memento Event Logging tool   |

## Environmental conditions

|                                   |   |
|-----------------------------------|---|
| Operating ambient air temperature | -40 to +85 °C / -40 to +185 °F, with conduction cooling (ambient temperature measured inside the enclosure) |
| Operating ambient air humidity    | 0 to 100% RH non-condensing   |
| Storage ambient air temperature   | -55 to +100 °C / -67 to +212 °F   |
| Storage ambient air humidity      | 0 to 100% RH non-condensing   |

## Certifications

|                                 |   |
|---------------------------------|---|
| Electromagnetic - EMC standards | <ul style="list-style-type: none"> <li>• European Council EMC Directive 2004/108/EC</li> <li>• United States FCC rule 47 CFR 15</li> </ul>                                |
| EMC - Emission                  | <ul style="list-style-type: none"> <li>• EN 55022:2010 Class B</li> <li>• FCC 47 Part 15 Class B</li> </ul>   |
| EMC - Immunity                  | <ul style="list-style-type: none"> <li>• EN 55024:2010 Class B</li> <li>• EN 61000-4-3</li> <li>• EN 61000-4-4</li> <li>• EN 61000-4-5</li> <li>• EN 61000-4-6</li> </ul> |
| Flammability                    | PCB compliant with UL 94 V-0  |
| RoHS                            | European Union Directive 2011/65/EU (ROHS2)   |



|       |  |
|-------|--|
| REACH | European Union Regulation 1907/2006  |
| WEEE  | Must be disposed of separately from normal household waste and must be recycled according to local regulations |

---

### Ordering Information

---

|                            |  |
|----------------------------|--|
| Product code - Description | <ul style="list-style-type: none"><li>• 1629 - Coaxlink Duo PCIe/104-EMB</li></ul>   |
| Optional accessories       | <ul style="list-style-type: none"><li>• 3300 - HD26F I/O module for Coaxlink Duo PCIe/104</li><li>• 3301 - Thermal drain (Model 1) for Coaxlink Duo PCIe/104</li><li>• 3302 - DIN1.0/2.3 Coaxial cable for Coaxlink Duo PCIe/104</li></ul> |

---



## AMERICA

### **Euresys Inc.**

27126-B Paseo Espada - Suite 704  
San Juan Capistrano, CA 92675 - United States

Phone: +1 949 743 0612

Email: [sales.americas@euresys.com](mailto:sales.americas@euresys.com)

## EMEA

### **Euresys SA**

Liège Science Park - Avenue du Pré Aily, 14  
4031 Angleur - Belgium

Phone: +32 4 367 72 88

Email: [sales.europe@euresys.com](mailto:sales.europe@euresys.com)

## EMEA

### **Sensor to Image GmbH**

Lechtorstrasse 20 -  
86956 Schongau - Germany

Phone: +49 8861 2369 0

Email: [sales.europe@euresys.com](mailto:sales.europe@euresys.com)

## ASIA

### **Euresys Pte. Ltd.**

750A Chai Chee Road - #07-15 Viva Business Park  
Singapore 469001 - Singapore

Phone: +65 6445 4800

Email: [sales.asia@euresys.com](mailto:sales.asia@euresys.com)

## CHINA

### **Euresys Shanghai Liaison Office**

Unit 802, Tower B, Greenland The Center - No.500 Yunjin Road, Xuhui District  
200232 Shanghai - China

Euresys上海联络处

上海市徐汇区云锦路500号绿地汇中心B座802室  
200232

Phone: +86 21 33686220

Email: [sales.china@euresys.com](mailto:sales.china@euresys.com)

## JAPAN

### **Euresys Japan K.K.**

Expert Office Shinyokohama - Nisso Dai 18 Building, Shinyokohama 3-7-18  
Kouhoku-Ku, Yokohama-Shi 222-0033 - Japan

〒222-0033

神奈川県横浜市港北区新横浜3-7-18 日総第18ビル エキスパートオフィス新横浜

Phone: +81 45 594 7259

Email: [sales.japan@euresys.com](mailto:sales.japan@euresys.com)

More at [www.euresys.com](http://www.euresys.com)

